


# **Fire Magic**<sup>®</sup>

**The Ultimate Barbecue**


**FLAT ROTISSERIE BASKET**

**Model # 3618**



## **ASSEMBLY**

1. Insert the spit rod (supplied with your rotisserie kit) through the openings in the end brackets of the basket (Figure 1). You may need to loosen the thumb screws.
2. Center the basket on the spit rod and secure with the thumb screws (Figure 1). Rotate the rotisserie so that the cover is up.
3. The cover is removed by “squeezing” the loops together (Figure 1).
4. Place your items to be cooked into the basket. Squeeze the loops together and place the cover firmly down on the items and release the rods of the cover into the notches (Figure 1).
5. Use the counterbalance (supplied with your rotisserie kit) to properly balance the spit rod.



This manual may not be copied, photocopied, reproduced, translated, or published in any electronic or machine-readable form in whole or in part without prior written approval of Robert H. Peterson Co.

**We reserve the right to amend product specifications without prior notice.**

**Robert H. Peterson Co. 14724 East Proctor Avenue, City of Industry, CA 91746**