



Non-Stick Fire Magic Wok

E-Z Assembly Instructions



Power Burners as well as with normal indoor cooking ranges.

The nonstick wok will not peel, blister or warp under normal useage and is safe for use with metal utensils. The easily assembled set comes in 8 pieces and by following the instructions below, it only takes a few minutes to put together, using $a^{3}/_{8}$ flat blade screwdriver.

Parts List

an E-Z clean, non-stick surface for carefree and healthy cooking. The wok has a 14³/₄" diameter and is compatible with all Fire Magic Barbecues, Sideburners and

- 1. Wok Base Pan
- 2. Wok Handle (black)
- 3. Steel Handle Washer
- 4. Handle connecting Rod
- 5. Wok Lid
- 6. Slotted Connecting screw
- 7. Wok Lid Handle bezel
- 8. Wok Lid Handle

The 3 Stage E-Z Assembly of Wok Base Handle.

- 1) Taking the black handle (Item 2), insert the six-sided end into the receiving hole on the base pan (Item 1).
- 2) Slide steel washer (Item 3) onto the threaded handle connecting rod (Item 4).
- 3) Insert the rod through the handle, into the the base pan and tighten, locking the handle into place. (TAKE CARE NOT TO OVER TIGHTEN)

The 3 Stage E-Z Assembly of Wok Lid Handle.

- 1) Taking the wok lid (Item 5) and inverting it, push the slotted screw (Item 6) through the hole on the center of the lid.
- 2) Place the silver and black wok lid handle (Item 8) into the handle bezel (Item 7) and place over center hole in the lid.
- **3)** Push the screw into the hole in the lid handle and tighten, using a ^{3/}₈" flat blade screwdriver. (TAKE CARE NOT TO OVER TIGHTEN)

ROBERT H. PETERSON CO. • 14724 East Proctor Avenue, City of Industry, Ca 91746

REV A 030405 L-C2-10405